# XPRESS LIGHT LED MAGNIFIER LAMP

# **MANUAL GUIDE**

PLEASE READ ALL THE SAFETY INSTRUCTIONS THOUGHTFULLY BEFORE THE DEVICE OPERATION. KEEP THIS MANUAL GUIDE SAFE FOR FUTURE REFERENCE.

# PRODUCT INTRODUCTION

The XPRESS LIGHT LED Magnifier Lamp is used for the work area proper lightningand magnifying. The XPRESS LIGHT LED Magnifier Lamp is a clever aid with its 3D Magnifier Lens, adjustable light body, Touch luminescence control and LED light source for the high level of professional work.

# SPECIFICATION:

Input: AC100-240V, 50/60Hz Output: DC12V, 0.8A Power (W): 8W±10% Measure (mm): 1010\*170\*40mm Weight (a): 990a Light source: LED bulb Magnifier Lens: 3Dioptre, 5" ACCESSORIES:

# - 1pcs Holding Clamp

- 1pcs AC Adapter

#### OPERATION

ATTENTION! Before the device operation, always check the device and its accessories just state.

- **[1.1]** Unpack the device and its accessories from the packaging then select a stable-, horizontal-, even surfaced place for the device use.
- **12.1** Secure the Holding clamp to the selected surface:
  - Twist the Holding clamp bottom fixing screw to a fully open state. The round hole of the Holding clamp has to be faced upwards.
  - Place the Holding clamp to the surface until it stops.
  - Hold still the Holding clamp, than fasten it to the surface with the bottom fixing screw till it stops, Attention! Pay attention not to overdo the fastening, because it can cause damage to the Holding clamp or to the surface.
  - The correctly secured Holding clamp cannot be loose- or move on the surface.
  - Now the device can be applied into the Holding clamp [see at **OPERATION [ 3.]**].
  - For the Holding clamp removal, see **CLEANING/MAINTENANCE** chapter **Holding Clamp**.
- 13.1 Hold steady the device with both hands, than place its bottom Holding shaft to its full length into the Holding clamp hole till it stops.
- [4.] Adjust the device desired position with the Arms and Head piece. The Head piece position can be adjusted with turn it to up- or down till 180° or to sideways with 360° turn. Notice: during in the first install it may occur that the plastic parts of the device are sill stiff e.g.: Head piece or the plastic screws on the Arms. Pay attention not to apply too much tension to
- [5.] Connect the device AC adapter to the outlet than to the device Adapter socket.
  - Connect the AC adapter to the Adapter socket as the following: place the AC adapter end to the device Adapter socket opening. At the end of the AC adapter there are two nibs standing out. At the sides of the device connecting socket there are two holes. Pay attention that the nibs of the AC adapter and the holes of the device socket to be stand in line on top of each other. Connect the two ends till it stops, than turn the AC adapter end to the way of the smaller hole of device socket. With this move the two ends are secured together. The separation of the AC adapter and the device Adapter socket are take place in the reverse order.
- [6.1] For the device operation press the ON/OFF "I/O" button shortly at the bottom of the Head piece.
- [7.] Adjust the desired light luminance with a long, continues press at the ON/OFF "I/O" button in the bottom of the Head piece. If you would like to modify the adjusted luminance, press again continuously the ON/OFF "I/O" button at the bottom of the Head piece. Notice: the device will keep the last adjusted luminance.
- **[8.1]** For the Magnifier Lens use, place the Head piece above the object, than open the Lens cover panel. Look into the Magnifier Lens from 10-15cm above, than adjust the desired distance between the object and the Head piece. If the Magnifier Lens use is finished, close the Lens cover lid, than adjust the device Headpiece position.
- 19.1 At the end of the device use press shortly the ON/OFF "I/O" button at the bottom of the Head piece, than remove the AC adapter from the device Adapter socket [see at OPERATION [ 5.] ] and from the outlet as well.

[ EN ] XPRESS LIGHT LED MAGNIFIER LAMP [ HU ] XPRESS LIGHT NAGYÍTÓS LED LÁMPA [ RO ] LAMPA CU LUPA XPRESS LIGHT LED [ DE ] XPRESS LIGHT LED LUPENLEUCHTE [ FR ] LAMPE LOUPE XPRESS LIGHT LED [ IT ] LAMPADA CON LENTE DI INGRANDIMENTO XPRESS LIGHT LED [ ES ] LÁMPARA CON LENTE MAGNIFICADOR XPRESS LIGHT LED

## **CLEANING/MAINTENANCE**

ATTENTION! DO NOT dissemble the device! The device does not require inner cleaning/maintenance. Before the cleaning/maintenance always make sure the device annealed state [turn off the device, than remove the AC adapter from the device and form the outlet as well. Always proceed with the cleaning/maintenance after the device full cool down! It is recommended to wear gloves during in the procedure.

Tools for the cleaning/maintenance: Compressed Air, Brush and a Non-synthetic soft, clean dry cloth. Device: Remove the device from the Holding Clamp. Hold the device stable, than pull out the device bottom shaft from the Holding Clamp with vertical linear movement. After the device is removed, place it to an even surfaced stable place lit is recommended to put a soft, dry cloth under the device). Wipe out the device external panel and the Magnifier Lens both sides with the dry, soft cloth. Clean the device hard to reach parts as well [switcher, joints] with brush and compressed air. Wipe out the device external panel again with the dry, soft cloth than place back the device to its original position [see at Operation [3.1]. For the last step check the device correct operation [see at Operation [4.1 - [7.1]].

Holding Clamp: Remove the device from the Holding clamp [see at CLEANING/MAINTENANCE Device chapter], than remove the Holding clamp from the surface. Hold still the Holding clamp, than twist its bottom fixing screw to a fully open state than remove the Holding clamp from the surface with care. Wipe out the Holding clamp external panel with a dry, soft cloth than clean it's hard to reach parts as well with brush and compressed air. Wipe out the external panel again with the dry, soft cloth than place back the Holding clamp to the surface [see at Operation [ 2.1]. For the last step place back the device to its original position [see at **Operation [ 3.1**].

Notice! For tenacious contaminations, the device external panel, Holding Clamp external panel and the Magnifier Lens can be cleaned with a lightly moist soft cloth, but pay attention that the device cannot have liquid inside in it or in its switcher, joints or to become contacted with the device AC Adapter or the device Adapter socket. After the moist cleaning, do not put the device under it charge at least 1-2min and always wait for its full dry. Do not use solvent detergents!

In case of average frequency use, clean the device- and its accessories at least once a week according to the described above. The device LED light bulb panel cannot be changed at home. The Light bulb panel change requires an authorized person. If the replace is necessary, look for the place of purchase and as for professional help.

Store the device and its accessories always in a dry place, far from radiant heat in a clean state. Wind the AC Adapter power cord loosely together, pay attention not to break it.

Before the device operation always check the device and its accessories just state.

# **SAFETY CAUTIONS**

- [1.] Only for indoor use, between 0~40°C [32~104°F]!
- Before the device operation always make sure the device and its accessories just state.
- The device cannot be left behind without supervision when it is turned on.
- Use/store the device only in stable, even surfaced places. Do not put the device into places where it can be knocked down or may fall off.
- The device or its accessories cannot become contact with liquids.
- Do not ever touch the device- or its accessories with wet/moist hands.
- Do not ever operate the device if any parts of it are damaged or had any kind of accident or fell into water! Take the device into the place of purchase for repair and seek for professional help.
- [8.] Only authorized personals can repair the device- or its accessories.
- 19.1 Use/store the device in a dry place far from radiant heat, in a clean environment, Avoid moist/wet and contaminated places.
- [10.] Do not look directly into the device light source during in operation.
- [11.] The device can have electric charges in it even if it is turned off. After the device use is finished, always anneal it [turn off the device than remove the AC adapter from the device and from the outlet as well.

For more information about the device, visit our website: http://www.crystalnails.com or look for the place of purchase.

### NOTICE!

If any case of malfunction was found or any parts of the device has to be replaced/repaired, please look for the place of purchase.

Importer: Elite Cosmetix LTD.; Jozsef Krt. 44., H-1085 Budapest, Hungary

[1/1.]